


# ANALOG INPUTS AINP2 - APPLICATION DIAGRAM

## ANALOGOVE VSTUPY AINP2 - APLIKACNI SCHEMA


POTENTIOMETER

POTENCIOMETR




ANALOGUE DIFERENTIAL INPUT +-10V

ROZDILOVY VSTUP +-10V




TEMPERATURE SENSOR

SNIMAC TEPLoty



ANALOGUE INPUT +-10V

ANALOGOVY VSTUP +-10V



PRIKLAD KONFIGURACE VSTUPU:

INPUTS CONFIGURATION EXAMPLE:


CONF:

000  
111  
222  
333

P1	P2	P3	P4	P5	P6
POT	POT	POT	POT	POT	POT
ADIF	---	ADIF	---	ADIF	---
---	PT100	---	PT100	---	PT100
AINP	AINP	AINP	AINP	AINP	AINP

MAXIMALNE MUZE BYT PRIPOJENO 6 POTENCIOMETRU NEBO 3 ANAL. DIFERENCIALNI VSTUPY NEBO 3 SNIMACE PT100 NEBO 6 JEDNODUCHYCH ANALOGOVYCH VSTUPU.

MAX. 6 POTENTIOMETERS, OR 3 ANAL. DIFERENTIAL INPUTS, OR 3 TEMP. SENSORS PT100, OR 6 SINGLE ANALOG INPUTS.



MEFI s.r.o		
Size	Document Number	REV
A	AINP2E	
Date:	January 14, 2002	Sheet 3 of 3